


MBSoiling Station– 700 Series

Advanced Soiling Station Series



Document ID: M4 028 010 010 01 (R2)

Revision 1.03 2022/05/29

SW 2.10



M. B. Control & Systems Pvt. Ltd.

CIN : U67120WB1980PTC033012 | PAN : AABCM7980K | GST NO. : 19AABCM7980K1ZU

Registered & Corporate Office

31/1, Ahiripukur Road, Kolkata, West Bengal 700019 | +91 98313 30473, 98312 06454

+91 033 2287 0445 | enquiry@mbcontrol.com | www.mbcontrol.com

Innovative Electronics For You



Table of Contents

1. Warnings.....	5
2. MBSoiling Station	6
2.1 MBSoiling Station Applications	6
2.2 Soiling Parameters	6
2.3 MBSoiling Station Models	7
3 MBSoiling Station Installation	9
3.1 MBSoiling Station With Solar Charger:	9
3.2 MBSoiling Station – Without Solar Charger:	11
3.3 MBSoiling Station - Cleaning:	12
3.4 MBSoiling Station Controller Connections.....	13
3.4.1 PV Panel Interface.....	13
3.4.2 MBSoiling Station Power Supply Connections.....	14
3.4.3 Serial Port -RS485.....	15
3.4.4 Port ETH	16
3.4.5 SD Memory Card.....	17
3.4.6 Internal Modem (Optional).....	18
4 Embedded Webserver	20
4.1 User Login.....	21
4.2 Welcome Page.....	22
4.3 Soiling Station Configuration Files.....	23
4.4 Device Configuration.....	25
4.5 Measurement Panels Configuration:	26
4.6 Soiling Parameters	27
2022.01.3 Soiling Calculation.....	27
4.6.2 Solar Panel Parameters.....	28
4.6.3 Soiling Parameters	29
4.7 Configure – Datalogging Files	29
4.7.1 Day Log File Configuration:	31
4.7.2 Remote File Transfer Configuration:.....	32

4.8	Configure – Cellular Modem	35
4.9	Configure – Serial Port (RS485)	35
4.10	Configure – ETH Network.....	38
4.11	Configure – SNTP Client	39
4.12	MyPage Parameters.....	40
4.13	User Configuration.....	41
4.14	Commit Configuration	41
5	Embedded Webserver– Diagnostics.....	43
5.1	MBSoiling Station Status	44
5.1.1	MBSoiling Station Status	44
2022.01.3	Soiling Station Modem Status	45
5.2	MyPage Parameters.....	46
5.3	Data Log Files	46
5.3.1	DataLog Files – Day	47
2022.01.3	DataLog Files RFT-1 and RFT-2.....	48
5.4	Soiling Parameters.....	49
5.5	Soiling Station Messages	50
5.5.1	Download Device Status Report	50
2022.01.3	Download Device Value Report	51
2022.01.3	Delete MBLogger Messages	51
5.6	Solar Panel Offset Calibration.....	52
6	Soiling Station Messages	53
6.1	Soiling Station Information Messages	53
6.2	Soiling Station Fault Messages	57
7	Technical Specifications.....	58
2022.01	General Specifications:	58
7.2	Measurement Parameters:.....	58
7.3	Communication Serial Port (RS485):.....	58
7.4	Communication Port ETH.....	58
7.5	Internal Modem	59
7.6	Datalogging	59
7.7	Electrical.....	59
7.8	Environmental.....	59
7.9	Physical.....	59
8	Soiling Station MODBUS Slave Registers	60
8.1	Soiling Station Time	60

8.2	My Parameters	60
8.3	Soiling Parameters	61
8.4	Measurement Panel Parameters	61
9	Soiling Station Diagnostics.....	64
10	Soiling Station Library.....	67
10.1.	Library for Solar Panels.....	67
11	Revision History.....	68

1. Warnings

- Installation at site should be done by skilled and qualified personal after taking required approvals.
- Use proper protection gear and tool while installing the device.
- Be aware of your surroundings while doing the installation work.
- Serious injury can occur if proper safety norms are not followed.
- Compliance with all utility and electrical safety codes regulations are mandatory.
- Read the manual and get acquainted with the datalogger connections and terminals before commencing installation activity.
- Before connecting the datalogger, read its label to confirm power supply requirements.
- All connections should be done only when power to device is switched off.
- Improper installation and connections may damage the device and sensors connected to the same.
- Protect from overvoltage and static electricity.
- To prevent potential fire or shock hazard, do not expose the datalogger to rain or moisture.
- Physically damaged equipment should not be used or connected to main power.
- Use proper earth connection.

2. MBSoiling Station

MBSoiling Station series-700is advanced range of soiling station. The soiling station provides following advanced functions:

3. Uses latest ARM 32 bits processor.
4. Real time monitoring of clean and soiled PV panels.
5. Regular monitoring and filtering of soiling parameters.
6. All measurements are available via serial RS485 (MODBUS RTU) and ETH (MODBUS TCP) ports.
7. Modem 4G (optional) for communication of logged files to remote servers.
8. MODBUS TCP (master and slave), SNTP, FTP and DNS.
9. All parameters are available as MODBUS (RTU or TCP) slave parameters.
10. External SD memory card (16GB) for data logging.
11. Programmable data logging interval.
12. Embedded webserver for configuration of soiling functions and diagnostics (real time view of measured parameters). No programming is required.
13. MyPage – to display user selected parameters in one webserver page.
14. Internal battery backed up real time clock (RTC).
15. Data file transfer to two file servers.
16. Internal memory of 32MB and expandable SD card memory up-to 16GB.
17. Log for user activity and device messages/ faults.
18. Calibrate soiled panel with respect to clean panel.
19. Powered via solar charge PV panel or AC power supply.
20. Optional – automatic cleaning of soiled and clean panels. With monitoring of cleaning liquid level in the tank.
- 21. Excellent on-site diagnostic support with soiling station status and value reports.**

2.1 MBSoiling Station Applications

The soiling station is used to measure power generation losses due to soiling of panels in of photovoltaic plant. Number of soiling stations to be installed in a plant will depend on its topology and size. Guidelines provided in IEC-61724-1 should be followed.

Soiling station can be used in various applications:

- Site resource and generation capacity assessment.
- Scheduling of PV panel cleaning.
- Plant performance evaluation.

2.2 Soiling Parameters

Following soiling parameters are measured and calculated:

Sl. No.	Parameter	Description
1	Clean Panel Voltage	Clean Panel open circuit voltage
2	Clean Panel Current	Clean Panel short circuit current
3	Clean Panel Temperature	Clean Panel temperature

4	Soiled Panel Voltage	Soiled Panel open circuit voltage
5	Soiled Panel Current	Soiled Panel short circuit current
6	Soiled Panel Temperature	Soiled Panel temperature
7	Reference panel Effective Irradiation - EffRadClean	Calculated based on panel short circuit current and panel temperature for reference panel. This calculation also compensates for the panel temperature and the panel temperature coefficient.
8	Soiled panel Effective Irradiation - EffRadSoil	Calculated based panel short circuit current and panel temperature for soiled panel. This calculation also compensates for the panel temperature and the panel temperature coefficient.
9	Soiling Ratio	EffRadSoil/ EffRadClean
10	Soiling Index (%) (SLI)	(1- EffRadSoil/ EffRadClean)*100. This calculation is also compensated for calibration constant of soiled panel.

Table -2.2: Soiling parameters

2.3 MBSoiling Station Models

Various options and models available are shown in table 2.3 below:

Sl. No.	Features	700XXX 700XXH	700XXM 700XXH	700CXX 700CXH	700CMX 700CMH
1	Port Serial Port -1 RS-485 (MODBUS RTU Slave)	•	•	•	•
2	Port ETH (MODBUS TCP Slave, Web Server, FTP and SNTP)	•	•	•	•
3	Cellular Modem	-	•	-	•
4	MMC SD Card (16GB)	•	•	•	•
5	Maximum number of MODBUS TCP Slave clients	4	4	4	4
6	SNTP Client	1	1	1	1
7	File Transfer Clients	2	2	2	2
8	RTC (battery backed up)	•	•	•	•
9	Solar PV Power supply	•	•	-	-
10	AC Power supply	•	•	•	•
11	Auto Panel cleaning	-	-	•	•

Table-2.3: Soiling Station models

Note: C: Soiling station with cleaning option.

M: Soiling station with modem

H: Soiling station with high wattage solar panel

3 MBSoiling Station Installation

MBSoiling Station connections are described in this section. All connections described here may not be available in your soiling station. Features and connections available will depend on the model selected.

3.1 MBSoiling Station With Solar Charger:

Soiling station can be powered via solar PV panel or AC power supply. Diagram for soiling station is shown in figure 3.1 below.




Fig - 3.1 Soiling station with solar charger

Parts of soiling station with solar charger are listed in table-3.1 below.

Sl. No.	Part	Model	Description
Soiling Station			
1	Pole	MS Pole- three meters	Galvanized pole with tripod and accessories.

	Measurement panels boom Pipes		Galvanised- for installing measurement solar panels along with mounting accessories.
2	Panel Clean	50W	Clean solar panel
3	Panel Soiled	50W	Soiled solar panel
4	Temperature sensor – clean panel	MBMet-801B-3000	PT1000 with three meters cable
5	Temperature sensor – soiled panel	MBMet-801B-3000	PT1000 with three meters cable
7	Lightning Arrester		Copper
8	Copper strip	25x2.5mm – Five meters	For earthing lightening arrestor
9	Solar charging panel	50W	Solar charging panel
10	Charging panel boom Pipes		Galvanised- for installing charging solar panel along with mounting accessories.
11	Cables		Required interconnecting cables
Soiling Station Control Box			
1	Soiling station controller	MBMet-700X	Soiling station controller as per selected model
2	Battery charger		Battery charger
3	Battery	16AH	Battery to power soiling station
4	AC Power supply	12V/ 3A	Backup power supply
5	Enclosure		IP65
6	Enclosure mounting accessories		
7	Power supply and serial port protection devices		

Table- 3.1: Parts of soiling station

3.2 MBSoiling Station – Without Solar Charger:

Diagram for soiling station without solar charger is shown in figure 3.2 below.




Fig - 3.2 Soiling station without solar charger

Parts of soiling station without solar charger are listed in table-3.2 below.

Sl. No.	Part	Model	Description
Soiling Station			
1	Pole	MS Pole- three meters	Galvanized pole with tripod and accessories.
	Measurement panels boom Pipes		Galvanised- for installing measurement solar panels along with mounting accessories.
2	Panel Clean	50W	Clean solar panel
3	Panel Soiled	50W	Soiled solar panel
4	Temperature sensor – clean panel	MBMet-801B-3000	PT1000 with three meters cable
5	Temperature sensor – soiled panel	MBMet-801B-3000	PT1000 with three meters cable
7	Lightning Arrester		Copper

8	Copper strip	25x2.5mm – Five meters	For earthing lightening arrestor
9	Cables		Required interconnecting cables
Soiling Station Control Box			
1	Soiling station controller	MBMet-700X	Soiling station controller as per selected model
2	Enclosure		IP65
3	Enclosure mounting accessories		
4	Power supply and serial port protection devices		

Table- 3.2: Soiling station without solar charger

3.3 MBSoiling Station - Cleaning:

Clean panel of the soiling station should be cleaned periodically depending on local dust conditions. This should be done at least once in a day.

Soiled panel should be cleaned as per cleaning schedule of the generation PV panels.

3.4 MBSoling Station Controller Connections

Soling station controller connections are explained here.

3.4.1 PV Panel Interface

Connections for clean and soiled solar panels are shown in figure -3.4.1 below.




Figure-3.4.1: Clean and soiled panel connections

Details of measurement PV panels connections are provided below in table 3.4.1.

Terminal	Wire Colour	Description	Remarks
T18	White	W1	Clean panel temperature measurement using 3-wire RTD Connection.
T19	White	W2	
T20	Red	W3	
T21	Red	W4	
T22	White	W1	Soiled panel temperature measurement using 3-wire RTD Connection.
T23	White	W2	
T24	Red	W3	
T25	Red	W4	
T26	Red	Clean Panel +	Clean panel measurement
T27	Black	Clean Panel -	
T28	Red	Soiled Panel +	Soiled panel measurement
T29	Black	Soiled Panel -	

Table-3.4.1: Measurement solar panel connections

3.4.2 MBSoiling Station Power Supply Connections

Soiling station controller power supply connections are shown in figure 3.4.2 below. **These terminals are not plugin type.**




Figure-3.4.2: Soiling station controller power supply connections.

Power supply connections details are listed in table-3.4.2 below.

Terminal	Wire Colour	Function	Remarks
T1	Red	V+	Voltage Range: DC 9 to 32VDC Power Consumption (Without modem) – 4W Power Consumption (With modem)- 10W Use proper MCB.
T2	Green	Earth	
T3	Black	V-	

Table-3.4.2: Soiling station controller connections

3.4.3 Serial Port -RS485

Soiling station serial port - RS485 are shown in figure 3.4.3 below. This port can be used only as MODBUS slave to read soiling parameters.




Figure-3.4.3: Soiling station serial port-1 (RS485) connections.

Note: Serial port-2 is not used.

Connection details for the serial port are listed in table-3.4.3.1 below.

Terminal	Wire Colour	Function	Remarks
T7	White	A	Isolated RS485 port. LED Rx and Tx provide indication for port activity. Can operate only as MODBUS RTU Slave. Use low capacitance, twisted pair and shielded cable for connecting devices to the port.
T8	Green	Shield	
T9	Brown	B	

Table-3.4.3.1: Soiling station serial port- RS485 connections

Default configuration for the serial RS485 port is provided in table 3.4.3.2 below.

S. No.	Description	Value
1	Baud rate	9600
2	Data bits	8
3	Parity	None
4	Stop bits	1
5	MODBUS Slave address	1

Table-3.4.3.2: Default port configuration parameters

These parameters can be changed via the embedded web server.

3.4.4 Port ETH

This ETH port (base 10MHz) is multi- function port.




Figure-3.4.4.1: Soiling station ETH Port.

Use standard LAN cable with RJ 45 connector for connecting to the port.
Port activity LED are provided on the connector.

This port is used for following operations:

- i) Configuration of soiling station via embedded web server.
- ii) Downloading logged file.
- iii) MODBUS TCP slave (multiple masters) to provide measured and collected parameters to other devices and SCADA.
- iv) SNTP Client for time synchronization.
- v) File transfer client (ftp).

Configuration details for ETH port are provided [here](#).

Default network configuration for the ETH port is provided in table 3.4.4 below.

S. No.	Description	Value
1	Device IP	192.168.100.222
2	Network Mask	255.255.255.0
3	Network Gateway IP	0.0.0.0
4	Primary DNP IP	8.8.8.8
5	Secondary DNS IP	8.8.4.4

Table-3.4.4: Default ETH port network configuration

These parameters can be changed via the embedded web server.

Procedure for setting default IP address in the soiling station is provided below. This procedure should be followed only if IP address of the soiling station is not known. If

soiling station IP address is known, use webserver in the soiling station to set the required IP address.




Figure -3.4.4.2: Jumpers for setting default IP address in the soiling station.

1. For normal operation jumper 6 and 4 shall be in open condition.
2. For setting default IP address short jumper 6 and 4 for about two seconds.
3. Remove the jumper between 6 and 4.
4. Wait for about five seconds.
5. Soiling station will restart with default IP address. Only default IP address and Subnet shall be set to default values.
6. Verify default IP address by using ping and / or logging in the soiling station webserver.

3.4.5 SD Memory Card

Soiling station supports microSD memory card up-to 16GB.




Figure-3.4.5: Soiling station SD card slot.

MicroSD card is used for data logging.

Configuration of data logging operations can be done via webserver.

3.4.6 Internal Modem (Optional)

Availability of internal modem is based on selected model.

High speed 4G modem (CAT-1) is provided.




Figure-3.3.6: Soiling station internal modem.

Micro SIM slot is provided. Push the SIM inside to lock or un-lock the same.

Use the antenna provided along with the modem.

Contact our sales team if high gain antenna is required.

Modem configuration details are provided [here](#).

Details of modem status LEDs are provided in table-3.4.6 below.

LED	Colour	Remarks
Modem Status	Green	Always OFF: Modem not ready. Always ON: Modem ready for operation.
Net Status	Blue	Always OFF: Power OFF. Always ON: Searching for network. ON 200mSec and OFF 200mSec: 4G registered. ON 800mSec and OFF 800mSec: 2G/ 3G registered.

Table-3.4.6: Modem status LED.

The modem can be used for following operations:

- i) SNTP Client for time synchronization.
- ii) File transfer client (ftp).

Configuration details for the modem are provided here.

4 Embedded Webserver

MBSoiling station provides embedded webserver for configuration and diagnostics.

Following functionality is provided via the embedded webserver.


- i) Soling Station configuration.
- ii) Monitor measured parameters.
- iii) Download and delete logged files
- iv) User configuration.
- v) Soiling Station diagnostic messages
- vi) Dropdown list for section of pre-selected options.
- vii) Limit validation for configured parameter values.
- viii) Hoover (take cursor) over the parameter to get further details on the same.
- ix) Details of not all parameters have been provided in this manual (to reduce the size). Further details can be obtained by using hoover over the parameter.
- x) Auto configured parameters will not have editable configuration field.
- xi) Configuration of parameters not applicable will be disabled.
- xii) Limits are displayed for parameters with limits (allowed minimum and maximum values). Default values are provided for most of the parameters.
- xiii) After editing any parameter click the cursor on any part of the screen. The parameter valued checked for errors and will be saved if there no error. If any error is found, same will be indicated on right hand top corner of the screen. Wrong values will not be saved and menu option for the parameter will turn **red** till the wrong value is corrected.
- xiv) All edited parameters will be **marked** till the same has not been committed.
- xv) Page menu option for the parameter will be marked with '**E**'. This mark will be provided at all hierarchy levels (up wards) till "MBLogger Configuration".
- xvi) All configuration of parameters will be saved on 'Commit' operation. Edit marks will also be removed from all edited parameters on 'Commit' operation being successful.

4.1 User Login

Use 'Chrome' to login to soiling station embedded web server.

Use soiling station IP (for first login – use soiling station default IP) to login.
Following login screen shall be displayed as shown in figure-4.1 below.

Soiling_Station-700 Configuration and Diagnostics - My Device



The login screen features a blue logo with the letters 'MB' at the top center. Below the logo is a white rectangular box containing two input fields: 'Username' and 'Password'. A blue button labeled 'Login' is positioned below the input fields.

Figure-4.1: Soiling station login screen.

User login details are provided in table 4.1 below.

User Type	Default Password	User Rights
Viewer	'Viewer'	Rights to view configuration and view diagnostic information.
Operator	'Operator'	All rights for configuration, operation, and diagnostics.
Admin	'Admin'	All rights for configuration, operation, diagnostics, and user configuration.
Maint	Not allowed	Maintenance user is used during manufacturing only.

Table-4.1: User login details

It is advisable that first login should be done by 'Admin' and then other users and their passwords should be configured.

4.2 Welcome Page

Upon successful user login, welcome page as shown in figure-4.2 is displayed.




Figure-4.2: User login welcome page.

The welcome page is self-explanatory, all the information required for configuration of the datalogger is provided on the page.

Details of welcome page are provided in table 4.2 below.

Object No	Description	Remarks
1	Username and role	Displays logged username and role.
2	'Logout'	Button for user logout. User will be automatically logged out if there is no keyboard or mouse activity for three minutes. User will be warned about this by warning sign on right hand top corner of the page. User can do any keyboard or mouse activity to reset the logout timer.
3	MBSoiling Station Configuration	Left click on this menu option to configure the soiling station. Menu options below will enable configuration all features of the datalogger. Left click on any menu option to configure the same.
4	Soiling station Diagnostics	Left click on this menu option to view soiling station diagnostics menu.

Table-4.2: Soiling station welcome page

Note:

If the user closes the webpage without logging out, user will have to wait for about three minutes prior to next login.

4.3 Soiling Station Configuration Files

Soiling station configuration files can be saved in the soiling station SD card.

Left click on menu option ‘Configuration Files’ to view the soiling station configuration files saved in the SD card shown in figure-4.3 below.




Figure-4.3: Soiling station configuration files.

Selected menu option shall be highlighted.

Operations available for soiling station configuration files are shown in table 4.3.1 below.

Sr. No	Operation	Action	Remarks
1	Save present soiling station configuration file	Right Click menu “Configuration Files” and select option “Save Present Configuration File” by left clicking on the option.	Soiling station configuration file will be saved in the SD Card and will be displayed in the list of configuration files saved. File name will model and serial number details.
2	Restore configuration	Right Click menu “Configuration Files” and select option “Restore Configuration” by left clicking on the option.	Soiling station configuration shall be restored in webserver. All edited ‘E’ parameters will be reverted to values and status as per current configuration of datalogger. This will be confirmed by removal of ‘E’ mark from all edited parameters.

3	Upload Configuration File	Right Click menu “Configuration Files” and select option “Upload Configuration File” by left clicking on the option.	Soiling station configuration file shall be uploaded from the selected directory in PC. Selected file shall be verified and will be uploaded only if the file all verification procedures.
---	---------------------------	--	--

Table-4.3.1: Soiling station configuration file operations

Options available for saved soiling station configuration files are shown in table 4.3.2 below.

Sr. No	Operation	Action	Remarks
1	Download File	Click on button “Download File” for the file to be downloaded.	Selected file will be downloaded on connect PC/ Laptop. File “Download Status” will show “File Downloaded”
2	Delete File	Click on button “Delete File” for the file to be deleted.	The file will be deleted and removed from the list. Deleted files cannot be restored.
3	Use file for configuration	Click on button “Conf File” for using the file for configuration.	The file will be validated. If validation is OK, soiling station configuration parameters will be displayed as edited parameters. Parameters which do not match with present configuration shall be marked with ‘E’. Use ‘Device Commit’ operation to configure the datalogger with the selected file.

Table-4.3.2: Operations for saved configuration files

4.4 Device Configuration

Left click on menu option ‘Device Configuration’ to configure soiling station parameters as shown in figure-4.4 below.




Figure-4.4: Configuration of soiling station parameters.

Selected menu option shall be highlighted.

Select the required tab to configure the tab parameters. Selected tab shall be highlighted.

Details of the page are provided in table 4.4 below.

Sr. No	Parameter	Description	Remarks
1	Device Name	Device Name.	Device name. – Default is ‘MyDevice’.
2	Site Name	Site Name	Site name – Default is ‘MySite’.
3	Set Device Time	Left click on the button ‘Set Device Time’ to synchronize the datalogger time with PC time	On successful operation, current time will be displayed.

Table-4.4: Configuration – soiling station

4.5 Measurement Panels Configuration:

Soling station panel configuration can be seen by clicking on menu “Panel Configuration” as shown in figure – 4.5 below:




Figure-4.5: Soiling station panel parameters

Details of the page are provided in table 4.5 below. These parameters are not editable at site.

Sr. No	Parameter	Description	Remarks
1	Clean Panel Parameters		
1.1	Model	Panel model	Installed panel model
1.2	Watt	Panel Wp	Wp for the installed panel
1.3	Short Circuit Current	Panel short circuit current	
1.4	Panel Coefficient (%/°C)	Panel temperature coefficient	Will be as per as the panel being used.
	Soiled Panel Parameters		
2.1	Watt	Panel Wp	Wp for the installed panel
2.2	Short Circuit Current	Panel short circuit current	
2.3	Panel Coefficient (%/°C)	Panel temperature coefficient	Will be as per as the panel being used.
2.4	Coefficient	Default 1.00	Panel coefficient with respect to clean panel.

Table-4.5: Configuration – soling station panel parameters

4.6 Soiling Parameters

Soiling parameters configuration can be seen by clicking on menu “soiling Parameters”.

4.6.1 Soiling Calculation

Soiling Calculations can be configured by clicking on tab “Soiling Calculation” as shown in figure – 4.6.1 below:





Figure-4.6.1: Configuration Soiling calculation

Details of soiling calculation configuration are provided in table 4.6.1.1 below.

Sr. No	Parameter	Description	Remarks
1	Soiling Parameter Average	Averaging of soiling parameters	Default – Enable
2	Soiling Parameter Average Time (sec)	Soiling parameters average time (seconds)	Default – 900 second
3	Panel Parameter Average	Averaging of solar panel parameters	Default – Enable
4	Parameter Average Time (sec)	Solar panel parameters average time (seconds)	Default – 60 second

5	Minimum Irradiation Value	Soiling calculation will be done only if solar irradiation exceeds this minimum value.	Default 250 W/mtr2
---	---------------------------	--	--------------------

Table-4.6.1.1: Configuration – soiling parameters

Details of configuration of soiling measurement time are provided in table 4.6.1.2 below.

Sr. No	Parameter	Description	Remarks
1	Solar Noon Hours	Solar noon hour	Set solar noon time at site. This time will vary with month of the year.
2	Solar Noon Minutes	Solar noon minutes	
3	Measure Time - Minutes	Time in minutes during which soiling parameters will be measured.	This time together with solar noon time will be used to measure soiling.

Table-4.6.1.2: Configuration – soiling measurement time

Note: Measurement of soiling:

- i) Example: Solar noon is configured as 11 Hours and 30 minutes and measurement time is set as 60 minutes.
Soiling measurement will start at 10.30AM and stop at 12.30PM.
- ii) As per IEC standard soiling should be calculated between sixty minutes before solar noon and sixty minutes after solar noon.

4.6.2 Solar Panel Parameters

Datalogging of soiling panels parameter can be configured clicking on tab “Solar Panel” as shown in figure – 4.6.2 below:




Figure-4.6.2: Solar panel parameters

Datalogging of solar panel parameter can be enabled/ disabled as required.

4.6.3 Soiling Parameters

Datalogging of soiling parameters can be configured clicking on tab “Soiling Parameters” as shown in figure – 4.6.3 below:




Figure-4.6.3: Soiling parameters

Datalogging of soiling parameter can be enabled/ disabled as required.

4.7 Configure – Datalogging Files

All logged files are saved in SD memory card. The card should be formatted with ‘FAT32’ format before being inserted in SD card holder.

SD card should not be removed or inserted while the soiling station is powered On and in operation. Disconnect power to soiling station prior to inserting or removing the SD card.

Files are saved with .csv extension with date and time.

Details of data log directories are provided in table 4.7 below:

Sr. No	Directory Name	Description	Remarks
1	‘DirDataLogDay’	Stores day log files	Configure operation of day log files.
2	‘DirDataLogRFT1’	Stores files for remote file server 1	Configure operation of files for remote file server 1.
3	‘DirDataLogRFT2’	Stores files for remote file server 2	Configure operation of files for remote file server 2.

Table-4.7: Data log file directories

Soiling station will automatically create missing directories on the SD card.

Parameter values and its attributes will be saved in the data log files if the parameter is configured for datalogging (refer to configuration of individual parameter for more details).

Left click on menu option ‘Datalog Files’ to configure file operation as shown in figure-4.7 below.




Figure-4.7: Configuration of datalog file operations.

For parameters having pre-selected options, available options are provided as drop-down list.

Following log files can be configured:

- i) ‘Day Log File Configuration’: Day data log file.
- ii) ‘RFT1 Configuration’: Remote file transfer-1 configuration
- iii) ‘RFT2 Configuration’: Remote file transfer-2 configuration

4.7.1 Day Log File Configuration:

Configuration of day log file is shown in figure 4.7.1 below.




Figure-4.7.1: Day log file Configuration

Details of the parameters on the page are provided in table 4.7.1 below. For details on other parameters use hover feature of the webpage. Take cursor on the parameter object on the page and further information will be provided for the parameter.

Sr. No	Parameter	Description	Remarks
1	Status	Enable / Disable data log operation	If disabled, data log operation will be disabled
2	Log Parameter Quality	Enable/ Disable logging of parameter value quality.	Parameter value quality will be logged if enabled.
3	DataLog Time Period (sec)	Time period for logging data in seconds	
4	Day Log File Name	Provide required data log file name	Day data log files will be saved with this name suffixed by ‘_Day’. Time in ‘YYY_MM_DD’ format will be added to the file name. e.g. ‘MBDataLog_Day_2020_12_06’
5	Delete Oldest File on Directory Full	If the directory is full – oldest file is deleted so that new file can be added.	Disabled: Data logging will stop if the directory is full. Enabled: Data logging will continue after deleting the oldest file in the directory.

Table-4.7.1: Configuration – day data log file operation

4.7.2 Remote File Transfer Configuration:

Remote file transfer can be configured via tabs – ‘RFT1 Configuration’ and ‘RFT2 Configuration’. Configuration page is shown in figure 4.7.2 below.




Table-4.7.2: Configuration – remote file transfer operation

Details on file parameters on the are provided in table 4.7.2.1 below.

Sr. No	Parameter	Description	Remarks
1	Status	Enabled / Disabled data log operation	If disabled, data log operation will be disabled
2	File Transfer Medium	Select Port ETH or Cellular Modem	Logged files will be transmitted via the selected medium. Note: If cellular modem is selected as medium and the modem operation fails – file transfer will be attempted via ETH port (if the port is connected and the gateway connection is OK).
3	Delete Oldest File on Directory Full	If the directory is full – oldest file is deleted so that new file can be added.	Disabled: Data logging will stop if the directory is full. Enabled: Data logging will continue after deleting the oldest file in the directory.
4	New File Create Option	Select from ‘Each Day’ or ‘Each Transmission Period’	Each Day: New data log file will be created as start of each day. Each Transmission Period: New data log file will be

			created at start of each file transmission time period.
5	Add Param Description Header	Enabled or disabled	If enabled, parameter description header will be added to the file
6	Add Param Statistical Values	Enabled or disabled	Enabled: Calculated statistical values – minimum, maximum, average, standard deviation, and integrated value shall be added to the log (as per parameter configuration). Disabled: Only parameter value shall be added to the log.
7	Delete File after Transmission	Enabled or disabled	Enabled: Data log file shall be deleted after successful transmission. Disabled: Data log file will not be deleted after transmission.
8	File Name	Provide required data log file name	Data log files will be saved with this name. Time in ‘YYYY_MM_DD_HH_MM’ format will be added to the file name. e.g. ‘MBDataLog_2020_03_15_15_45’
9	File Server URL	URL for the file server	Data logger shall resolve the URL to get the file server IP address.
10	File server IP	IP address for the file server	
11	File server Username	Username for the client	
12	File server Password	Password for the client	FTP client will use the configured username and password to connect to the file server.
13	File Transmit Time Period (sec)	Files transmit time in seconds	Logged file will be transmitted after this time.

Table-4.7.2.1: Configuration – remote file transfer operation

Notes:

- i) If ‘Modem; is selected media for file transfer, and it fails, file transfer shall be tried via ETH port (if the link to configured gateway is OK).

Details for parameter descriptor header with statistical values are provided in table 4.7.2.2 below.

Sr. No	Column	Description	Remarks
1	Date	Date of logging	YYYY.MM.DD
2	Time	Time of logging	HH.MM.SS
3	Parameter Quality	Parameter Description_Qua	= '0' for bad quality = '1' for good quality
4	Parameter Value	Parameter Description_Val. For sensors and IED connected to datalogger ports refer to table – 6.5.2.3.	Value in float
5	Parameter minimum Value	Parameter Description_Min	Minimum value in float
6	Parameter maximum Value	Parameter Description_Max	Maximum value in float
7	Parameter average Value	Parameter Description_Avg	Average value in float
8	Parameter standard deviation Value	Parameter Description_SD	Standard Deviation value in float. This value shall be provided if its calculation is enabled.
9	Parameter Integrated Value	Parameter Description_Int	Integrated value in float. This value shall be provided if its calculation is enabled.
10	Next parameter quality		

Table-4.7.2.2: Parameter descriptor header with statistical values

Details for parameter descriptor header without statistical values are provided in table 4.7.2.3 below.

Sr. No	Column	Description	Remarks
1	Date	Date of logging	YYYY.MM.DD
2	Time	Time of logging	HH.MM.SS
3	Parameter Value	Parameter Description_Val. For sensors and IED connected to datalogger ports refer to table – 6.5.2.3.	Value in float

4	Next parameter value		
---	----------------------	--	--

Table-4.7.2.3: Parameter descriptor header without statistical values

4.8 Configure – Cellular Modem

This option will be displayed only if the modem is installed.

Use micro-SIM with 4G service (preferable, 2G can also be used).

Left click on menu option ‘Cellular Modem’ to configure internal modem operation as shown in figure-4.8 below.




Figure-4.8: Configuration of internal cellular modem.

Configuration details of modem parameters on the page are provided in table 4.8 below.

Sr. No	Parameter	Description	Remarks
1	Cellular Service Provider	Select cellular service provider	Select the service provider from the dropdown list. If ‘None’ is selected, modem operation will be disabled.
2	Cellular service APN	APN for the service provider	APN will be auto configured based on the selected service provider.

Table-4.8: Configuration – datalogger modem

4.9 Configure – Serial Port (RS485)

Serial port – RS485 can be used as MODBUS RTU Slave.

Use low capacitance, twisted pair and shielded cable for connection of sensors and IED’s to this port.

Left click on menu option ‘Serial Port RS485’ to configure this port as shown in figure-4.9 below.




Figure-4.9.1: Configuration of serial port RS485.




Figure-4.9.2: Configuration of serial port RS485 – MODBUS Slave parameters.

Configuration details of communication parameters for serial port RS485 are provided in table 4.9 below.

Sr. No	Parameter	Description	Remarks
1	Port Service	Select service for the port: MODBUS master or MODBUS slave	Only MODBUS Slave service is allowed.

Table-4.9: Configuration – serial port RS485

4.10 Configure – ETH Network

Left click on menu option ‘ETH Network’ to configure soiling station ETH network and its services as shown in figure-4.10 below.




Figure-4.10: Configuration of soiling station ETH network.

Configuration details for ETH port are provided in table 4.10 below.

Sr. No	Parameter	Description	Remarks
1	Data Logger IP	Data logger IP	
2	Data Logger Subnet mask	Data Logger Subnet mask	
3	Network Gateway IP	Network Gateway IP	This IP shall be used for internet access via ETH port
4	Primary DNS IP		Set primary DNS
5	Secondary DNS IP		Set secondary DNS

Table-4.10: Configuration – ETH Port parameters

Details for tabs for configuration of services on ETH port are provided in table 4.10 below.

Sr. No	Tab	Description	Remarks
1	MODBUS TCP Slave	Configure MODBUS TCP slave service	

Table-4.10: Configuration – ETH port services

4.11 Configure – SNTP Client

SNTP client can be used to synchronize internal clock of the soiling station. The client can be used to operate via datalogger network or internal modem.

Up-to NTP time servers can be configured. SNTP client will switch over to next time server if any server fails to respond.

Left click on menu option ‘SNTP Client’ for configuration as shown in figure-4.11 below.




Figure-4.11: Configuration of SNTP client.

SNTP client will operate in ‘Client Mode’ only.

Configuration details of SNTP clients are provided in table 4.11 below.

Sr. No	Parameter	Description	Remarks
1	NTP Server IP and URL	Configure NTP server IP or URL. Either of the two can be configured.	SNTP client will get time from any of the configured and working NTP servers. URL will be resolved if DNS are configured.

Table-4.11: Configuration – SNTP Client

Notes:

- i) If SNTP client fails to get time via the configured media. It will try to change the media (if alternate media is available) and get time.

4.12 MyPage Parameters

This unique feature allows user to configure required parameters of interest on one page for viewing on webserver and OLED. Maximum of 24 parameters can be configured. These parameters can also be accessed on MODBUS Slave port in sequential register addresses.

Left click on menu option 'MyPage' to configure analog input channels as shown in figure-4.12 below.




Figure-4.12: Configuration of MyPage.

Configuration details for MyPage parameters are provided in table 4.12 below.

Sr. No	Parameter	Description	Remarks
1	Parameter Source	Select source for the parameter. Dropdown list of available parameter sources.	Select 'Not Used' if parameter configuration is not required.
2	Parameter	Select the parameter of interest. Dropdown list of parameters configured in the selected source shall be provided.	Select 'Not Used' if parameter configuration is not required.
3	Parameter Attribute	Select the parameter attribute of interest. Dropdown list of available parameter attributes for the selected parameter shall be provided.	

4	MODBUS Register	MODBUS register address is provided for external device or SCADA to read value of the parameter.	Selected parameter attribute value is provided as 32 bits float registers. This field is not editable.
---	-----------------	--	--

Table-4.12: MyPage parameters configuration

4.13 User Configuration

Following types of users can be configured for soiling station operation:

- i) Administrator
- ii) Operator
- iii) Viewer

Left click on menu option ‘User Configuration’ to configure users shown in figure-6.16 below. Only ‘Administrator’ can configure usernames and their passwords.




Figure-4.13: User configuration.

Use tabs provided to configure the required user.

Configuration details of user configuration are provided in table 4.13 below.

Sr. No	Parameter	Description	Remarks
1	Username	Set username	Users with configured username and passwords will be allowed to operate the datalogger
2	User Password	Set user password	

Table-4.13: User configuration

4.14 Commit Configuration

All edited parameter values must be saved in the soiling station non-volatile memory – this is called ‘Commit Operation’. This will be allowed only if configuration of any parameter has been edited (marked by ‘E’).

Following actions will happen (in the listed sequence) once 'Commit' is initiated.

- i) All logged in users will be logged out.
- ii) All operations of the soiling station will be stopped. This may take some time.
- iii) New configured valued will be saved in internal non-volatile memory of the soiling station.
- iv) All operations of soiling station will resume with new configuration. This may take some time.
- v) User can login again (if required) with assigned credentials.

Left click on menu option 'MBSoiling Station Configuration' to select the same.

Right click on MBSoiling Station Configuration' to see the submenu option to commit the configuration as shown in figure-4.14 below.




Figure-4.14: Commit operation.

Note:

- i) **Once committed, the configuration cannot be reverted. It is irreversible operation. The soiling station must be re-configured if any change is required.**
- ii) **User will be logged out on commit operation. User can login again once the soiling station re-starts.**
- iii) **Soiling station will take few seconds to re-tart its operation.**


5 Embedded Webserver– Diagnostics

MBSoiling Station provides extensive diagnostics and monitoring functionality via webserver.

Following diagnostic features are provided:

- i) Monitor real time values from all inputs.
- ii) Monitor MyPage parameters
- iii) Status of datalogger resources
- iv) Messages from datalogger for user login history, operations, and hardware faults.
- v) All parameter values, their calculated statistical values and status will be updated in real time (at preset time interval). Animation is provided when the values are updated.
- vi) Parameter values will be updated with their quality. Bad quality values will be shown in red.

Left click on menu option ‘MBSoiling Station Diagnostic’ to open the diagnostic menu as shown in figure -5 below.



The screenshot shows a web browser window displaying the 'Soiling Station-700 - My Device' interface. The page title is 'Soiling Station Diagnostics' and the URL is '192.168.100.205/DeviceItemMenu.cgi?V=17331570&K=-2&ST=0&TT=0'. The user is logged in as 'Admin Role: Administrator'. The main content area displays a table titled 'Soiling Station Status' with columns for 'No', 'Description', and 'Status'. The table lists various parameters and their current values and statuses.

No	Description	Status
1	Water	0.0000000000000000
2	Temperature	0.00
3	Relative Humidity	0.00
4	Wind Speed	0.0000000000000000
5	Wind Dir	0.000000
6	Soiling Index	0.00
7	Soiling Index 2	0.000000
8	Water In	0.0000000000000000
9	Soiling Index	0.000000
10	Soiling Index	0.000000
11	Soiling Index	0.000000
12	Soiling Index	0.000000

Figure-5: MBSoiling Station diagnostic page.

5.1 MBSoiling Station Status

This status page displays status of datalogger services and modem status:

5.1.1 MBSoiling Station Status

Select tab ‘MBSoiling Station Status’ to view details of the soiling Station and status of services as shown in figure-5.1.1 below.




Figure-5.1.1: Soiling Station status.

Details for soiling Station status are provided in table 5.1.1 below.

Sr. No	Parameter	Description	Remarks
1	Model	Model details of the data logger	
2	Hardware Version	Hardware version for the model	
3	Software Version	Software version for the model	
4	Serial Number	Unique alphanumeric serial number for the datalogger	
5	File Name	Names of data log files	Data log files will be created with this name and will be suffixed by date and time
6	No Param Logged		Number of parameters configured for logging
7	SD Card	Status of SD card	Display –‘Installed’ or ‘Not Installed’
8	Device IP	IP address for the datalogger	

9	ETH Gateway	Status of network gateway	Display 'Link Fail' if link to gateway fails. Display 'Link OK' if link to gateway is OK.
10	SNTP Client	Status of SNTP client	Display status of SNTP client.
11	RFT Server-1	Status of remote file transfer server -1	
12	RFT Server-2	Status of remote file transfer server- 1	

Table-5.1.1: Soiling Station status

2022.01.3 Soiling Station Modem Status

This tab will be displayed on if the modem is installed. Select tab 'Modem Status' to view status of soiling station internal modem as shown in figure-5.1.2 below.




Figure-5.1.2: Soiling station modem status.

Details for soiling station modem are provided in table 5.1.2 below.

Sr. No	Parameter	Description	Remarks
1	Initialisation Status	Modem initialisation status	
2	Registration status	Modem registration status	
3	Operating mode	Modem operation mode	Modem network operation mode – 'None', 'GSM', 'GPRS', 'EDGE', or 'LTE'
4	Signal Strength	Cellular signal strength	Signal strength in dBm
5	Bit error rate (BER)	Bit error rate	

Table-5.1.2: Datalogger modem status

5.2 MyPage Parameters

Left click on diagnostic menu option ‘MyPage Parameters’ to view MyPage parameters as shown in figure 5.2 below.

The screenshot shows a web browser window displaying the 'Soiling Station-700 - My Device' interface. The page title is 'My Page' and the user is logged in as 'Admin' with the role of 'Administrator'. A sidebar menu on the left contains options like 'Soiling Station Configuration', 'Soiling Station Diagnostics', 'My Page', 'Datalog Files', 'Parameters', 'Device Messages', 'Soiling Station Maintenance', and 'Maintenance'. The main content area displays a table of parameters. The table has five columns: 'Parameter No.', 'Parameter Source', 'Parameter', 'Parameter Attribute', and 'Parameter Value'. The first few rows are visible, showing parameters like '1', '2', '3', '4', '5' with their respective sources and values.

Parameter No.	Parameter Source	Parameter	Parameter Attribute	Parameter Value
1	1000-1000	1000-1000	1000	1000
2	1000-1000	1000-1000	1000	1000
3	1000-1000	1000-1000	1000	1000
4	1000-1000	1000-1000	1000	1000
5	1000-1000	1000-1000	1000	1000

Figure-5.2: MyPage parameters.

Values of all parameters configured as MyPage Parameters will be displayed on the page.

5.3 Data Log Files

Status of all data log files can be viewed via this page. Files can also be deleted or downloaded via click buttons provided.

Left click on diagnostic menu option ‘Datalog Files’ to view details of logged files.

Three tabs are provided for data log files:

- i) ‘Data log Files Day’: Day data log files.
- ii) ‘Data log Files RFT-1’: Data log files for remote file server-1.
- iii) ‘Data log Files RFT-2’: Data log files for remote file server-2.

5.3.1 DataLog Files – Day

Day log file status is shown in figure 5.3.1 below.



Figure-5.3.1: Day Data log files

Details file status and operation are provided in table 5.3.1 below.

Sr. No	Parameter	Description	Remarks
1	File name	Logged file name	
2	Time	File log time	
3	Size	File size in Bytes	
4	Download Status	Download status of the file	File not downloaded – ‘File Not Downloaded’ File downloaded – ‘Downloaded’
4	Delete File button	Left click on the button to delete the file.	Files delete operation is irreversible. Active file – file that is being logged cannot be deleted. ‘Delete Button’ shall be disabled for this file.
5	Download File button	Left click on the button to download the file.	The file will be downloaded to PC or Laptop. Status of the file will be changed to ‘Downloaded’. This button will not be available if the file is being logged.

Table-5.3.1: Day data log files

2022.01.3 DataLog Files RFT-1 and RFT-2

Select the required tab for viewing status of remote file transfer operation.

Remote Transfer log file status is shown in figure 5.3.2 below.




Figure-5.3.2: Remote transfer data log file status

Details file status and operation are provided in table 5.3.2 below.

Sr. No	Parameter	Description	Remarks
1	File name	Logged file name	
2	Time	File log time	
3	Size	File size in Bytes	
4	Transmit status	Transmit status of the file	File not transmitted – ‘Not Transmitted’ File not transmitted – ‘Transmitted’
5	Download Status	Download status of the file	File not downloaded – ‘File Not Downloaded’ File downloaded – ‘Downloaded’
6	Delete File button	Left click on the button to delete the file.	File delete operation is irreversible. Active file – file that is being logged cannot be deleted. ‘Delete Button’ shall be disabled for this file.
7	Download File – button	Left click on the button to download the file.	The file will be downloaded to PC or Laptop. Status of the file will be changed to ‘Downloaded’.

			This button will not be available if the file is being transmitted or being logged.
--	--	--	---

Table-5.3.2: Remote transfer data log files

5.4 Soling Parameters

Soiling parameters can be viewed in real time clicking on ‘Soiling Parameters’. Select tab ‘Solar Panel’ to view panel parameters as shown in figure-5.4.1 below.




Figure-5.4.1: Solar panel parameters

Select tab ‘Soiling Parameters’ to view soiling parameters as shown in figure-5.4.2 below.




Figure-5.4.2: Soiling parameters

5.5 Soling Station Messages

Left click on diagnostic menu option ‘Device Messages’ to view messages from soling station as shown in figure 5.5 below.

Logged messages shall be displayed on the page. Soling station message details are provided in [this chapter](#).




Figure-5.5: Soling Station messages

Details of soling station messages are provided in table 5.5 below.

Sr. No	Parameter	Description	Remarks
1	Description	Message description	Hardware faults will be displayed in red .
2	Message Code	Message code	

Table-5.5: Soling Station messages

Following operation are possible:

- i) Download Device Status Report
- ii) Download Device Value Report
- iii) Delete Soling Station Message

Click on the option required.

5.5.1 Download Device Status Report

Click on this option to download status of soling station in .txt file. It will also download logged messages.

Downloaded file will have following information:

- i) Date and time of report
- ii) Model and serial number details.
- iii) Status of services on the soling station.
- iv) Status of sensors connected.
- v) List of all the messages logged.

2022.01.3 [Download Device Value Report](#)

Click on this option to download values of all parameters from all inputs in .txt file.

Downloaded file will have following information:

- i) Model and serial number details.
- ii) All measured values and quality.

Following information is provided in this report:

- i) Date and time of report
- ii) Description of parameters.
- iii) **'Qual'**: quality of parameter value. Good quality values will be marked as 'GD'. Bad quality values will be marked as 'IV'.
- iv) **'Value'**: parameter value in float format.
- v) **'Value_Min'**: minimum value of the parameter for the block time.
- vi) **'Value_Man'**: maximum value of the parameter for the block time.
- vii) **'Value_Avg'**: average value of the parameter for the block time.
- viii) **'Value_SD'**: Standard deviation for the parameter. It will be displayed only if the same is enabled in parameter configuration.
- ix) **'Value_Int'**: Integrated value for the parameter. It will be displayed only if integration is enabled in parameter configuration.

2022.01.3 [Delete MBLogger Messages](#)

This option is not available.

5.6 Solar Panel Offset Calibration

This operation can be done by only “Maint’ user.

This operation calibrates parameters of soiled panel with clean panel. The operation should be done under following conditions only.

- i) Clear sunny day with no clouds.
- ii) At solar noon.
- iii) Solar irradiation should be more than 0.8 sun.

Refer to the screen shown in figure 5.6 below.




Figure-5.6: Panel offset calibration

Select “Calibration Start’ in row ‘Panel Offset Calibration’.

Panel offset calibration will be done automatically and will be over in about 30 seconds.

Select “Calibration Stop’ in row ‘Panel Offset Calibration’ and logout.

6 Soiling Station Messages

Soiling station provides messages for the following events:

- i) User login and logout
- ii) Datalogger re-configuration
- iii) Hardware faults

Details of message types are provided in table-6 below.

Sr. No	Message Type	Remarks	Action Required
1	Information	Information message. No effect on operation of the datalogger.	None
2	Fault	Hardware fault. Operation of the datalogger will be affected. Red Led 'ER' on front panel will flash.	Contact service@mbcontrol.com

Table-6: Datalogger message types

6.1 Soiling Station Information Messages

MBLogger operation information messages are listed in table-8.1 below.

Sr. No	Code	Message	Message Type	Remarks
1	1000	Power On	Information	
2	1001	Re-Conf	Information	Datalogger has been re-configured
3	1002	Adm Login	Information	Administrator login and logout
4	1003	Adm Logout	Information	
5	1004	Opr Login	Information	Operator login and logout
6	1005	Opr Logout	Information	
7	1006	Viw Login	Information	Viewer login and logout
8	1007	Viw Logout	Information	
9	1008	Login Fail	Information	Invalid login attempt
10	1010	Time SyOK	Information	Time synchronisation OK after fail
11	1011	Time SyFail	Information	Time synchronisations fail
12	1012	DL Msg Deleted	Information	Data logger messages have been deleted.
13	1014	RFT1 Comm Media Fail	Information	Communication media for remote file transfer -1 has failed
14	1015	RFT1 Comm Media OK	Information	Communication media for remote file transfer -1 is OK

15	1016	RFT1 Connect ETH Fail	Information	Connection to remote file server -1 has failed via ETH port
16	1017	RFT1 Connect ETH OK	Information	Connection to remote file server -1 is OK via ETH port
17	1018	RFT1 File Write Fail	Information	File write operation for remote file server -1 has failed
18	1019	RFT1 File Write OK	Information	File write operation for remote file server -1 is OK
19	1020	RFT1 File Open Fail	Information	File open operation for remote file server -1 has failed
20	1021	RFT1 File Open OK	Information	File open operation for remote file server -1 is OK
21	1022	RFT1 File Close Fail	Information	File close operation for remote file server -1 has failed
22	1023	RFT1 File Close OK	Information	File close operation for remote file server -1 is OK
23	1024	RFT1 File Transmit Fail	Information	File transmit operation for remote file server -1 has failed
24	1025	RFT1 File Transmit OK	Information	File transmit operation for remote file server -1 is OK
25	1026	RFT2 Comm Media Fail	Information	Communication media for remote file transfer -2 has failed
26	1027	RFT2 Comm Media OK	Information	Communication media for remote file transfer -2 is OK
27	1028	RFT2 Connect ETH Fail	Information	Connection to remote file server -2 has failed via ETH port
28	1029	RFT2 Connect ETH OK	Information	Connection to remote file server -2 is OK via ETH port
29	1030	RFT2 File Write Fail	Information	File write operation for remote file server -2 has failed
30	1031	RFT2 File Write OK	Information	File write operation for remote file server -2 is OK
31	1032	RFT2 File Open Fail	Information	File open operation for remote file server -2 has failed

32	1033	RFT2 File Open OK	Information	File open operation for remote file server -2 is OK
33	1034	RFT2 File Close Fail	Information	File close operation for remote file server -2 has failed
34	1035	RFT21 File Close OK	Information	File close operation for remote file server -2 is OK
35	1036	RFT2 File Transmit Fail	Information	File transmit operation for remote file server -2 has failed
36	1037	RFT2 File Transmit OK	Information	File transmit operation for remote file server -2 is OK
37	1038	Modem PPP Link Up	Information	Modem PP Link is OK
38	1039	Modem PPP Link Down	Information	Modem PP Link has failed. All communication via modem will be stopped.
39	1040	RTC OK	Information	RTC is operating OK
40	1041	Modem File Transfer ETH	Information	File is being transmitted via ETH port instead of Modem. This can happen if the modem has failed and file transfer via ETH port is possible.
41	1042	Modem File Transfer Modem	Information	File transmission via Modem has been restored.
42	1042	Modem File Transfer Modem	Information	File transmission via Modem has been restored.
43	1043	Modem Fail Recovery	Information	Modem failure has been recovered
44	1044	ETH Port Not Connected	Information	ETH port is not connected to any network
45	1045	ETH Port Connected	Information	ETH port is connected to network
46	1046	Maint Login	Information	Maintenance user login and logout
47	1047	Maint Logout	Information	
48	1048	Calibration Mode Start	Information	Datalogger is in calibration mode
49	1049	Calibration Mode End	Information	Datalogger is in normal mode of operation
50	1050	Device Restart	Information	Device has re-started itself.
51	1051	Task Termination Fail	Information	System message for tasks operation

52	1052	Messages Deleted	Information	Logged messages have been deleted.
53	1053	RFT1 Connect Modem Fail	Information	Connection to remote file server -1 has failed via Modem
54	1054	RFT1 Connect Modem OK	Information	Connection to remote file server -1 is OK via Modem
55	1055	RFT2 Connect Modem Fail	Information	Connection to remote file server -2 has failed via Modem
56	1056	RFT2 Connect Modem OK	Information	Connection to remote file server -2 is OK via Modem
57	1057	SNTP Media Change Modem	Information	SNTP client media has been changed from ETH to Modem. This will happen if SNTP client fails to connect to time server via ETH network and modem is working OK.
58	1058	SNTP Media Change ETH	Information	SNTP client media has been changed from Modem to ETH. This will happen if SNTP client fails to connect to time server via modem and ETH network is working OK.
59	1061	Serial Port2 Re Conf	Information	Serial port port-2 has been re-configured
60	1062	ADC-1 Fail	Information	ADC-1 operation failed
61	1063	ADC-1 Error	Information	ADC-1 error
62	1064	ADC-1 Reg Error	Information	ADC-1 register read error
63	1065	ADC-1 ReInit OK	Information	ADC-1 re-initialisation is OK
64	1066	DayLog File Write fail	Information	Error in writing to data log file
65	1967	RFT1Log File Write Fail	Information	Error in writing to remote file server-1 data log file
66	1068	RFT2Log File Write Fail	Information	Error in writing to remote file server-2 data log file
67	1069	Config File Write Fail	Information	Error in writing to device configuration file
68	1070	File Write size mismatch	Information	Mismatch in size of file being written

Table-6.1: Datalogger operation information messages

6.2 Soiling Station Fault Messages

Soiling station operation fault messages are listed in table-6.2 below.

Sr. No	Code	Message	Message Type	Remarks
1	2000	QSPI Fail	Fault	Internal non-volatile memory fail. Datalogger will not function.
2	2001	SDRAM Fail	Fault	Internal memory fail. Datalogger will not function.
3	2002	ADC-1 Fail	Fault	Analog input channels – PT1000 will not operate.
4	2004	Modem Fail	Fault	Internal modem will not function. This will affect functions working via modem.
5	2006	RTC Fail	Fault	RTC operation has failed. It will affect all time-based operations
6	2007	RTCbackupFail	Fault	RTC time was not backed up. Change the RTC backup battery
7	2008	ADC-1 SPI initialisation Fail	Fault	Fault in ADC-1
8	2022	Data Flash Fail	Fault	Fault in controller data flash memory
9	2024	Serial Port 2 Fail	Fault	Fault in datalogger serial port- 2
10	2025	ADC-1 ReInit Fail	Fault	Re-initialisation of ADC-1 failed

Table-6.2: Soiling station operation fault messages

7 Technical Specifications

2022.01 General Specifications:

Sr. No	Parameter	Specification
1	Micro-Processor	32 bits ARM Processor
2	RTC	Temperature compensated. RTC

Table-7.1: Soiling Station controller general specifications

7.2 Measurement Parameters:

Sr. No	Parameter	Range	Resolution
1	Measurement Panel clean – voltage	40V	0.01V
2	Measurement Panel clean – short circuit current	10A	0.01A
3	Measurement Panel clean – Temperature	-40 to 90°C	0.1°C
4	Measurement Panel soiled – voltage	40V	0.01V
5	Measurement Panel soiled – short circuit current	10A	0.01A
6	Measurement Panel soiled – Temperature	-40 to 90°C	0.1°C
7	Accuracy		0.2%
8	Noise filter		Notch at 50Hz and 60Hz

Table-7.2: Measured Parameters

7.3 Communication Serial Port (RS485):

Sr. No	Parameter	Specification
1	Baud rate	4,800, 9,600 and 19,200 bps
2	Isolation	2.5KV
3	Protocols	MODBUS RTU Slave

Table-7.3: Serial Port (RS485)

7.4 Communication Port ETH

Sr. No	Parameter	Specification
1	Speed	100MHz
2	Protocols	MODBUS TCP Slave SNTP client, FTP, HTTP, Embedded web server

Table-7.4: Port ETH

7.5 Internal Modem

Sr. No	Parameter	Specification
1	Modem Type	Quad band 4G (CAT-1) modem with antenna.
2	Frequency band	TDD LTE: B40/B41 GSM: 900/1800Mhz

Table-7.5: Internal Modem

7.6 Datalogging

Sr. No	Parameter	Specification
1	Datalogging time (periodical time)	Site configurable
2	SD Card	Up-to 16GB (FAT32)
3	Protocol	FTP via ETH port or inbuilt Modem

Table-7.6: Datalogging operation

7.7 Electrical

Sr. No	Parameter	Specification
1	Power supply voltage input	9-32 VDC
2	Power Consumption	With cellular modem: 6 W
		Without cellular modem: 4 W

Table-7.7: Electrical specifications

7.8 Environmental

Sr. No	Parameter	Specification
1	Operating Temperature range	-5°C to +60°C
2	Storage Temperature	-20°C to +80°C
3	Operating Humidity	Maximum 95% - noncondensing

Table-7.8: Environmental specifications

7.9 Physical

Sr. No	Parameter	Specification
1	Protection	IP20
2	Dimensions (W x H x L)	90 x 62 x 162 mm
3	Weight	0.5 Kg (59pprox..)
4	Mounting	DIN Rail
5	Housing material	Polycarbonate

Table-7.9: Physical specifications

8 Soiling Station MODBUS Slave Registers

All soiling station parameters are available via MODBUS slave registers.

Details of these registers are provided in this section.

8.1 Soiling Station Time

Sr. No	Parameter	Register Address	Type	Read/ Write
1	Soiling station epoch second	10	32 bits unsigned integer	Read/ Write

Table-8.1: Soiling station RTC time

Note: For writing time to datalogger – 32 bits should be written with write command.

8.2 My Parameters

Sr. No	Parameter	Attribute	Register Address	Type	Read/ Write
1	My Parameter-1	Value	20	32 bits float	Read only
2	My Parameter-2	Value	22	32 bits float	Read only
3	My Parameter-3	Value	24	32 bits float	Read only
4	My Parameter-4	Value	26	32 bits float	Read only
5	My Parameter-5	Value	28	32 bits float	Read only
6	My Parameter-6	Value	30	32 bits float	Read only
7	My Parameter-7	Value	32	32 bits float	Read only
8	My Parameter-8	Value	34	32 bits float	Read only
9	My Parameter-9	Value	36	32 bits float	Read only
10	My Parameter-10	Value	38	32 bits float	Read only
11	My Parameter-11	Value	40	32 bits float	Read only
12	My Parameter-12	Value	42	32 bits float	Read only
13	My Parameter-13	Value	44	32 bits float	Read only
14	My Parameter-14	Value	46	32 bits float	Read only
15	My Parameter-15	Value	48	32 bits float	Read only
16	My Parameter-16	Value	50	32 bits float	Read only
17	My Parameter-17	Value	52	32 bits float	Read only
18	My Parameter-18	Value	54	32 bits float	Read only
19	My Parameter-19	Value	56	32 bits float	Read only
20	My Parameter-20	Value	58	32 bits float	Read only
21	My Parameter-21	Value	60	32 bits float	Read only
22	My Parameter-22	Value	62	32 bits float	Read only
23	My Parameter-23	Value	64	32 bits float	Read only
24	My Parameter-24	Value	66	32 bits float	Read only

Table-8.2: My Parameters

8.3 Soiling Parameters

Sr. No	Parameter	Register Address	Type	Read/ Write
1	Soiling Ratio	10602	32 bits float	Read only
2	Soiling Ration – Day average	10604	32 bits float	Read only
3	Soiling Index (%)	10606	32 bits float	Read only
4	Soiling Index (%) – Day average	10608	32 bits float	Read only
5	Soiling measurement time	10600	32 bits – unsigned	Read only

Table-8.3: Soiling parameters

8.4 Measurement Panel Parameters

Sr. No	Parameter	Register Address	Type	Read/ Write
1	Panel Clean Parameters			
1.1	Effective Irradiation (W/mtr2)	10610	32 bits float	Read only
1.2	Short Circuit Currents (Amps)	10612	32 bits float	Read only
1.3	Voltage (V)	10614	32 bits float	Read only
1.4	Panel Temperature (°C)	10616	32 bits float	Read only
2	Panel Soiled Parameters			
2.1	Effective Irradiation (W/mtr2)	10618	32 bits float	Read only
2.2	Short Circuit Currents (Amps)	10620	32 bits float	Read only
2.3	Voltage (V)	10622	32 bits float	Read only
2.4	Panel Temperature (°C)	10624	32 bits float	Read only

Table-8.4: Measurement panels parameters

8.5 Cleaning System Configuration Parameters

Applicable only for soiling stations with auto cleaning system.

Cleaning system configuration parameter registers.

Sr. No	Parameter	Register Address	Type	Read/ Write
1	Auto clean enable b0: =1 for auto clean enable =0: for auto clean disable	10650	16 bits Unsigned Integer	Read / Write
23	Reference panel cleaning time – Hours (0-23)	10651	16 bits Unsigned Integer	Read / Write

3	Reference panel cleaning time – Minutes (0-59)	10652	16 bits Unsigned Integer	Read / Write
4	Reference panel number of cleaning cycles (1-10)	10653	16 bits Unsigned Integer	Read / Write
5	Reference panel clean ON Time (sec) (5-99)	10654	16 bits Unsigned Integer	Read / Write
6	Reference panel clean OFF Time (sec) (5-99)	10655	16 bits Unsigned Integer	Read / Write
7	Soiled panel number of cleaning cycles (1-10)	10656	16 bits Unsigned Integer	Read / Write
8	Soiled panel clean ON Time (sec) (5-99)	10657	16 bits Unsigned Integer	Read / Write
9	Soiled panel clean OFF Time (sec) (5-99)	10658	16 bits Unsigned Integer	Read / Write

Table-8.5: Cleaning system configuration parameters

8.6 Cleaning System Control Parameters

Cleaning system command registers.

Sr. No	Parameter	Register Address	Type	Read/ Write
1	Reference Panel Cleaning control (i) b0: Start b1: Stop	10660	16 bits Unsigned Integer	Write only
2	Soiled Panel Cleaning control (ii) b0: Start b1: Stop	10661	16 bits Unsigned Integer	Write only
3	Cleaning Hardware b0: Pump On b1: Valve Clean b2: Valve Soiled	10662	16 bits Unsigned Integer	Write only

Table-8.6: Cleaning system control parameters

Note:

- i) Reference panel cleaning control: ‘Start’ will start the cleaning operation of reference panel. It will stop after completing the cleaning cycles as configured via the webserver. ‘Stop’ will terminate cleaning operation of the reference panel.
- ii) Soiled panel cleaning control: ‘Start’ will start the cleaning operation of the soiled panel. It will stop after completing the cleaning cycles as configured via the webserver. ‘Stop’ will terminate cleaning operation of the soiled panel.
- iii) The pump and valves will be on for the time configured via the web server if Power Supply is available and water level is above the low level.

8.7 Cleaning System Status Parameters

Cleaning system status registers.

Sr. No	Parameter	Register Address	Type	Read/ Write
1	Cleaning System Status b0: Cleaning System Power Status b1: Water Level Low b2: Water Level High b3: Pump Status b4: Valve Clean Panel b5: Valve Soiled Panel b6: Reference Panel clean ON b7: Soiled Panel clean ON	10663	16 bits Unsigned Integer	Read only
2	Cleaning Cycle Number	10664	16 bits Unsigned Integer	Read only
3	Pump ON Remain Time	10665	16 bits Unsigned Integer	Read only
4	Pump OFF Remain Time (sec)	10666	16 bits Unsigned Integer	Read only

Table-8.7: Cleaning system status parameters

10 Soiling Station Diagnostics

Configuration and operation of MBSoiling Station is quite simple. It can be easily configured using the default settings.

Some of the probable problems and solutions are listed below.

10.1 Download Device Status and Values Report:

Download status report and logged messages as shown in sec. 7.7.1. and sec. 7.7.2. This report will enable better understanding of the problem.

10.2 Embedded Webserver

Sr. No.	Problem	Solutions
1	Unable to login to Device	<ul style="list-style-type: none"> i) Check that proper IP set in the device is being used. ii) Try default device IP. iii) Confirm that there is no IP clash in the network. iv) Check that IP set is as per network class. v) If user has closed the webpage without logout – wait for about three minutes before attempting next login.
2	Unbale to login. Message ‘Soiling Station is being configured. Login after some time’.	This message is generated if user tries to login while the device is being configured. Try to login after 10 to 15 seconds.

Table-11.2: Embedded webserver problems

10.3 ETH Network

Sr. No.	Problem	Solutions
1	SNTP client not able to update time.	<ul style="list-style-type: none"> i) Check that network gateway has been configured properly and connected to the LAN. Check gateway status on webserver diagnostics. ii) Check availability of internet. iii) Verify NTP server IP set in the Device. vi) Verify operation of the NTP server via ping.

Table-9.3: ETH Network problems

10.4 Soiling Station Modem

Sr. No.	Problem	Solutions
1	Modem is unable to register to network.	i) Check cellular signal strength via webserver diagnostic.

		<ul style="list-style-type: none"> ii) Connect the antenna securely and place the antenna to get best signal strength. iii) Verify that SIM is inserted properly. iv) Verify correct selection of cellular service provider. v) Check that there is enough balance in the SIM for data communication
--	--	--

Table-9.4: Soiling station Modem

10.5 Soiling Parameters

Sr. No.	Problem	Solutions
1	Panel temperature	i) Check proper connection of the panel temperature sensor.
2	Panel voltage and current	i) Verify that panel has been connected properly.

Table-9.5: Soiling parameters

10.6 File Transfer Operation

Sr. No.	Problem	Solutions
1	File transfer not OK.	<ul style="list-style-type: none"> i) Check the media for file transfer Modem of ETH. ii) If modem is selected – check that no problem exists with modem. iii) If ETH is selected – check problems with ETH network. iv) Verify configuration of IP, username and passwords for remote file servers. v) Check file servers with ping

Table-9.6: File transfer Operation

10.7 Datalogging Operation

Sr. No.	Problem	Solutions
1	SD Card problem	<ul style="list-style-type: none"> i) Check SD Card status on OLED or webserver. ii) Check that SD card is inserted properly. iii) Put Off the datalogger, remove the SD card. Verify operation of SD card on PC or laptop. iv) If required format the SD card. Remember to save the logger files prior to formatting the SD card.
2	Parameter values are not being logged	i) Verify that datalogging operation is enabled for the remote server .

		<ul style="list-style-type: none"> ii) Check if the data log file directory is full. iii) Check configuration for file directory. iv) Verify that the parameter has been configured for logging.
--	--	---

Table-9.7: Datalogging Operation

For other problems please contact service@mbcontrol.com .

11 Soiling Station Library

List of libraries provided in MBSoiling Station is provided below.

Option of 'Input Not Used' is provided for all inputs, if the same is not used.

10.1. Library for Solar Panels

List of solar panels is provided in table-10.1 below. This selection can be done at MBCS works only.

Sr. No.	Panel Wp	Comment
1	35Wp	To be selected during system configuration.
2	50Wp	

Table-10.1: Library of solar panels

12 Revision History

Revision	Date	Description
1.01	2022-01-01	Document created
1.02	22-03-18	Procedure for setting default IP is added.

Table-11: Revision History